



15160015



Key	Part No	Description	Key	Part No	Description
1	B07-0017030042	Flange	29	B07-23839	Gasket
2	B07-834451	Clamp	30	B07-59638	Nipple
3	B07-0017030041	Gasket for Flange	31	B07-19814	Impulse Pipe Fixing
4	B07-61029	Cord Seal	32	B07-23912	Pressure Switch
5	B07-0005040026	Pressure Nipple 90°	33	B07-58029	Pressure Nipple
6	B07-0017030015	End Cone	34	B07-31492	PVC Tube
7	B07-18476	Fixing Nut	35	B07-15995	Transformer
8	B07-0017030022	Burner Tube	36	B07-0005010152	Motor + Inverter
9	B07-59561	Hinge Assembly	37	B07-16952	Fan
10	B07-61007	Hinge Pin	38	B07-16936	Air Guide
11	B07-61153	Gas Elbow	39	B07-0017030030	Air Box
12	B07-0017030040	Gas Tube	40	B07-0017030032	Air Damper Pin
13	B07-61010	Pin	41	B07-0017030033	Air Damper Flap
14	B07-0017030038	Mixer	42	B07-0017030037	Bush
15	B07-0017030039	Bush	43	B07-0017030031	Air Inlet Guard
16	B07-0017030016	Brake Plate	44	B07-54059	Support
17	B07-0017030027	Bracket	45	B07-23205	Air Damper Motor
18	B07-0005060037	Ignition Cable Cap		B07-0005040027	Cover
19	B07-61299	Support	46	B07-0005040054	Potentiometer
20	B07-0010060084	Electrode	47	B07-0005150116	Rapid Connector
21	B07-30223	HT Cable	48	B07-30987	Impulse Pipe Fixing
22	B07-0017030028	Impulse Pipe	49	B07-31483	Pressure Nipple
23	B07-35623	Fixing Nut	50	B07-23845	T Connector
24	B07-4987	Washer	51	B07-0005150117	Olive
25	B07-0006020174	Connector	52	B07-0005150115	T Connector
26	B07-0017030029	Impulse Pipe			
27	B07-3172	Sight Glass Holder			
28	B07-0020020030	Sight Glass			
				TAV.C346	Control Panel

Control Panel - BGN 40 LX V

TAV.C346



Key	Part No	Description	Key	Part No	Description
1	B07-0010060098	Box			
2	B07-0006060008	Switch Panel			
3	B07-0005030071	Control Box			
4	B07-61228	Cover			
5	B07-7456	Fuse			
6	B07-0005120039	On/Off Switch			
7	B07-0005120040	Lock Out Light			
8	B07-0005120041	Auto/Man - Line Switch			
9	B07-0005120038	Manual Switch			
10	B07-30460	Overload			
11	B07-0005020034	Filter			
12	B07-23525	Wiring Base			
13	B07-0005110006	Relay Base			