


15160010




Key	Part No	Description
1	B07-0017030042	Flange bottom
2	B07-834451	Flange top
3	B07-0017030041	Gasket for Flange
4	B07-61029	Cord Seal
5	B07-0005040026	Pressure Switch
6	B07-0017030015	End Cone
7	B07-18476	Fixing Nut
8	B07-0017030022	Burner Tube
9	B07-59561	Hinge Assembly
10	B07-61007	Hinge Pin
11	B07-61153	Gas Elbow
12	B07-0017030040	Gas Tube
13	B07-61010	Pin
14	B07-0017030038	Mixer
15	B07-0017030039	Bush
16	B07-0017030016	Brake Plate
17	B07-0017030027	Bracket
18	B07-0005060037	Ignition Cable Cap
19	B07-61299	Suppor
20	B07-0010060084	Electrode
21	B07-30223	HT Cable
22	B07-0017030028	Impulse Pipe
23	B07-35623	Nut
24	B07-4987	Washer
25	B07-0006020174	Impulse Pipe Fixing
26	B07-0017030029	Washer

Key	Part No	Description
27	B07-3172	Sight Glass Holder
28	B07-0020020030	Sight Glass
29	B07-23839	Gasket
30	B07-59638	Nipple
31	B07-19814	Impulse Pipe Fixing
32	B07-23912	Pressure Switch
33	B07-58029	Pressure Nipple
34	B07-31492	PVC Tube
35	B07-15995	Transformer
36	B07-16897	Motor
37	B07-16952	Fan
38	B07-16936	Ring
39	B07-0017030030	Air Box
40	B07-0017030032	Air Damper Pin
41	B07-0017030033	Air Damper Flap
42	B07-0017030037	Bush
43	B07-0017030031	Guard
44	B07-54059	Support
45	B07-23205	Air Damper Motor
47	B07-0005150116	Rapid Connector
48	B07-30987	Impulse Pipe Fixing
49	B07-31483	Pressure Nipple
50	B07-23845	T Connector
51	B07-0005150117	Olive
52	B07-0005150115	T Connector
	<b>TAV.C279</b>	<b>Control Panel</b>

# Control Panel - BGN 40 LX

TAV.C279



Key	Part No	Description	Key	Part No	Description
1	B07-57332	Box			
2	B07-0006060006	Switch Panel			
3	B07-0005030071	Control Box			
4	B07-61228	Cover			
5	B07-7456	Fuse			
6	B07-0005120039	On/Off Switch			
7	B07-0005120040	Lock Out Light			
8	B07-0005120041	Auto/Man - Line Switch			
9	B07-0005130044	Manual Switch			
10	B07-0005110074	Overload			
11	B07-0005020034	Filter			
12	B07-23525	Wiring Base			
13	B07-0005110056	Contactor			