



BGN 40 Modulating ME



Key	Part No	Description	Key	Part No	Description
1	B07-834451	Half Flange	22	B07-3172	Sight Glass Holder
2	B07-61029	Cord Seal	23	B07-0020020030	Sight Glass
3	B07-34462	Gasket for Flange	24	B07-23839	O-ring
4	B07-0005140046	Ionisation Cable	25	B07-59638	Nipple
5	B07-61021	End Cone	26	B07-31053	Bush
6	B07-18476	Fixing Nut	27	B07-30245	Pressure Switch
7	B07-61154	Burner Tube	28	B07-15995	Transformer
8	B07-59561	Hinge Assembly	29	B07-16897	Motor
9	B07-61007	Hinge Pin	30	B07-16952	Fan
10	B07-61153	Gas Elbow	31	B07-16936	Air Guide
11	B07-61011	Gas Entry Tube	32	B07-0017030057	Air Damper Pin
12	B07-61018	Probe	33	B07-14212	Air Damper Flap
13	B07-61016	Mixer	34	B07-54056	Bush
14	B07-16905	Spacer	35	B07-34489	Air Inlet Guard
15	B07-16904	Brake Plate	36	B07-0006020266	Air Damper Flap
16	B07-0005060037	Ignition Cable Cap	37	B07-0006020188	Coupling
17	B07-61299	Support	38	B07-0010030086	Bracket
18	B07-61017	Electrode			
19	B07-30223	HT Cable			
20	B07-35623	Fixing Nut			
21	B07-4987	Washer			
				TAV.C336	Control Panel
				TAV.B270	Gas Train

Control Panel - BGN 40 Modulating ME


TAV.C336



Key	Part No	Description	Key	Part No	Description
1	B07-0012010100	Box	14	B07-0005130043	4 Pole Connector
2	B07-0006060008	Switch Panel	15	B07-0005030152	Display
3	B07-0006020268	MPA22 Controller	16	B07-0005130148	MPA22 Connector
4	B07-61228	Cover			
5	B07-7456	Fuse			
6	B07-0005120068	On/Off Switch			
7	B07-0005120053	Lock Out Light			
8	B07-0005120041	Auto/Man – Line Switch			
9	B07-0005120038	Manual Switch			
10	B07-0005110066	Overload			
11	B07-0006060019	Switch Panel Badge			
12	B07-0005130051	7 Pole Connector			
13	B07-0005110051	Contactor			

Gas Train - BGN 40 Modulating ME

TAV.B270



Key	Part No	Description	Key	Part No	Description
1	B07-0005040068	Pressure Switch		B07-0005090052	Valve
2	B07-23522	Pressure Connector	14	B07-0005090079	Coil
3	B07-0006020039	Flange DN40		B07-0005090081	Valve Stem
4	B07-23767	Gasket for Flange	15	B07-0005090053	Valve
5	B07-0006020256	Butterfly Valve		B07-0005090096	Coil
6	B07-23401	Flange DN40		B07-0005090083	Valve Stem
7	B07-0006020254	Position Indicator	17	B07-23521	Valve Connector
8	B07-0006020250	Coupling	18	B07-0010060030	Nipple
9	B07-0012010105	Spring	19	B07-4987	Washer
10	B07-0012010106	Pin	21	B07-30175	Reducing Nipple
11	B07-0022030047	Spacing Pillar	22	B07-0005150151	Nipple
12	B07-0012120092	Bracket			
13	B07-0006020265	Servo Motor			