



| Key | Part No        | Description           | Key | Part No          | Description              |
|-----|----------------|-----------------------|-----|------------------|--------------------------|
| 1   | B07-53672      | End Cone              | 21  | L01-LMG21.330B27 | Control Box              |
| 2   | B07-0020020123 | Flange Assembly       | 22  | M02-1-250-30     | Motor                    |
| 3   | B07-53610      | Air Adjustment Wheel  | 21  | B07-95080        | Capacitor                |
| 4   | B07-53726      | Gas Head              | 23  | B07-0005130096   | Motor Cable              |
| 5   | B07-53612      | Spacer                | 24  | B07-28718        | Spacer                   |
| 6   | B07-53621      | Probe                 | 25  | B07-49351        | Fan                      |
| 7   | B07-53620      | Electrode             | 26  | B07-0020020030   | Sight Glass              |
| 8   | B07-0005140114 | HT Cable              | 27  | B07-0019010010   | Bush                     |
| 9   | B07-0005140252 | Ionisation Cable      | 29  | B07-19945        | Probe Connector          |
| 11  | B07-0005140248 | Cable for Transformer | 30  | B07-23522        | Air Pressure switch Plug |
| 12  | F04-0004       | Transformer           |     |                  |                          |
| 13  | X01-0044       | 7 Pin Wieland Plug    |     |                  |                          |
| 14  | X01-0001       | 7 Pin Wieland Socket  |     |                  |                          |
| 16  | B07-47004      | Gasket for Flange     |     |                  |                          |
| 17  | B07-0005040062 | Pressure Switch       |     |                  |                          |
| 19  | L01-AGK11      | Base                  |     |                  |                          |
| 20  | B07-0005030012 | Cable Entry Plate     |     |                  |                          |