


15696920



Key	Part No	Description	Key	Part No	Description
1	B07-0020020027	End Cone	22	M02-1-370-03	Motor
2	B07-0020020120	Flange Assembly		B07-95079	Capacitor
3	B07-31514	Air Adjustment Wheel	23	B07-0005130096	Motor Cable
4	B07-54217	Gas Head	24	B07-28718	Spacer
5	B07-31528	Spacer	25	B07-61013	Fan
6	B07-53122	Probe	26	B07-0020020030	Sight Glass
7	B07-53121	Electrode	27	B07-0019010010	Bush
8	B07-0005140109	HT Cable	29	B07-19945	Probe Connector
9	B07-0005140252	Ionisation Cable	30	B07-23522	Air Pressure Switch Plug
11	B07-0005140248	Cable for Transformer	31	B07-0005040020	Servo Motor
12	F04-0004	Transformer	32	B07-0005120082	1 Stage Switch
13	X01-0044	7 Pin Wieland Plug	33	B07-0005120081	2 Stage Switch
14	X01-0001	7 Pin Wieland Socket	34	X01-0044	4 Pin Wieland Plug
16	B07-34462	Gasket for Flange	35	X01-0001	4 Pin Wieland Socket
17	B07-0005040062	Pressure Switch			
19	L01-AGK11	Base – LOA/LGB			
20	B07-0005030012	Cable Entry Plate			
21	B07-0005030084	Control Box			