

## Product Info

### Change of BHA-Adapter

---

September 2006

Page 1 of 1

---

In consequence of the introduction of Danfoss' new electronic burner controls, the BHO 70 Series, we have changed the BHA-adapter.

The reason for the change is that the BHO 70 series requires the LD/LDS connected to clamps 11 (blue) and 12 (black). A clamp on position 11 in the BHA-adapter has therefore been introduced.

So, when using the BHA-adapter together with the BHO 70 series, the LD/LDS wires must be moved from the old base part to clamps 11 and 12 in the BHA-adapter.

**Note!**

If the BHO 70 series is used for replacement of the BHO 64 series, which is already used together with the BHA-adapter, it is necessary to replace the BHA-adapter by the new version, because there is no clamp 11. You can also choose to replace the old Danfoss base part.

